

HANDLING THE SPEAKER

The speaker front and rear cases are secured with adhesive tape (2 points) at both sides when shipped from the factory.

CAUTION

Remove the tapes while placing the speaker on a stable surface or while supporting it with hand. Failure to do so may cause the case to fall, resulting in material damage and possible personal injury.

Before performing installation work, remove these tapes to separate front and rear cases.

Adhesive tapes

